

PC-USB ИНТЕРФЕЙС



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Адрес сайта: <https://seli.nt-rt.ru> || эл. почта: sfs@nt-rt.ru

PC-USB-Interface

Type ST-M12

PC-USB-Interface for readout and parameterize

Basic Features

- ▶ Construction: High-grade-steel sleeve with M12/4-plug
- ▶ Dimensions: L=70mm, W=18mm
- ▶ Cable Length: 1,7m
- ▶ USB-Connection: Type A, USB1.1 up to USB3.0
- ▶ Operating system: Windows 2000, XP, Vistax64, Windows 7, 8, 8.1, 10
- ▶ Supply voltage: 5VDC (USB-Bus)
- ▶ Power consumption: 75 mA
- ▶ Ambient temperature: 0...65°C
- ▶ Humidity: 0 to 75% (without condensation)
- ▶ Protection class: IP54
- ▶ Weight: 90g


Fields of application

PC Interface for parameterize active sensors, galvanically isolated

The programmer is designed to parameterize on maintenance visit . It connects seli devices with a PC via plug adapter.



Connection



M12 plug

- 1 GND
- 2 Tx (PC/USB Adapter)
- 3 Rx (PC/USB Adapter)
- 4 NC

Proper Plug Adapter

Not included - please order separately if necessary



ST-M12-MiniUSB

Adapter M12 for parameterization of SDT03, SMW-03 and MUK-V03



ST-M12-M8

Adapter M12/M8 to parameterize STS, STS01/02, STS03/04



ST-M12-KL (SNG-PA-M12)

3-pole jack plug 2,5mm to parameterize SNG



ST-M12-MM


8-pole red Micro plugs to parameterize SNKM



ST-M12-Y-AD

M12 cableadapter for parameterization of moulded units with M12 plug TF4x, SLI03, SGS02

Pin assignment ST-M12-Y-AD



Power supply and output

- 1 +VDC (red)
- 2 NC
- 3 GND (black)
- 4 OUT/PNP (white)



Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

Адрес сайта: <https://seli.nt-rt.ru> || эл. почта: sfs@nt-rt.ru